


Components

1. EVO-E Rechargeable Wireless Headset Mic
2. EVO-PREC Rechargeable Wireless Receiver
3. Headset Windscreen
4. 1/4" to 1/8" Cable
5. USB Power Adapter
6. Dual USB-C Charging Cable
7. Protective Neoprene Pouch
8. Quick Start Guide



Setup



1 Use the dual USB cable and USB power supply to charge the headset and receiver.



2 Using the 1/8" to 1/4" cable, connect the receiver to an input on your sound system/mixer.



3 Use the output, either mic or line level, that is appropriate for your sound system input.



4 The included adhesive backed hook and loop fastener can be used to attach the receiver as needed.



5 Turn on the receiver by pressing the power button.



6 Select a channel using the up and down buttons.



7 Turn on the headset by pressing the power button.



8 Select the channel matching the receiver using the channel select button.



9 Put on the headset, the strap can be used to adjust the fit.



10 Position the microphone at the corner of the mouth.



11 Turn up the volume on the sound system channel to the level needed.

**UHF
BAND**



SUPERIOR SOUND
FOR YOU



EVO-E

Water & Sweat Resistant Headset Mic &
Pocket-Sized Wireless Receiver Mic System

Quick Start Guide



FAQ

- 1. Q. How long does a charge last?**
A. About 4 hours

- 2. Q. Can I use the USB cable to give the Receiver continuous power?**
A. Yes, however if power is lost you will need to press the power button again.

- 3. Q. How do I know which output to use?**
A. If you do not know if your input is mic level or line level, start with the mic level output. If you are unable to get acceptable level/volume, move to the line level output.



BE HEARD™

Other Helpful Sources

EVO-E Product Page

EVO-E Quick Start
(PDF Download)

YouTube Channel

Specifications subject to change without notice.

601 E. Pawnee Wichita, KS 67211 316. 263.2852 FAX 316.263.0642 www.galaxyaudio.com
Distributed in Canada by Audio Distributors International (ADI) 1275 Newton, unit 6 Boucherville, QC J4B 5H2 Canada
450.449.8177 FAX 450.449.8180

Printed in China V20220331



BY SUPERIOR SOUND FOR YOU